






4





BOSS BS16

- (D) Montageanleitung
- (GB) Assembly instructions
- (ES) Instrucciones de instalación
- (FR) Instructions de montage
- (CZ) Montážní návod
- (PL) Instrukcja montażu
- (HU) Összeszerelési útmutató
- (SK) Montážny návod
- (RU) Инструкции по монтажу
- (IT) Istruzioni di montaggio
- (RO) Instrucțiuni de asamblare
- (TR) Montaj talimatı
- (NL) Handleiding voor de montage
- (UA) Інструкція монтажу








→ ↑ ↗
901x866x400






x2

1	901x400	8	811x110
2	868x376	9	892x196
3	866x376	10	892x196
4	866x376	11	892x196
5	868x62	12	841x356
6	350x110	13	880x404
7	350x110		







16x 8x30 K1	16x F15mm T1	16x F15mm M1	8x 1.2x20 G2	6x S2	4x 350mm P2	1x Z1	8x 4x25mm A9
18x 6,4x50 K3	24x 2x20 G3	4x U1	16x 6x13 A1	22x 3x16 A2	2x Z1	16x Z5	4x S3



3



2



1